Parkmaestro

Beyond Parking Guidance

User Interface User Manual

Teknotel Elektronik Ltd. Şti. Mimar Sinan Cad. No: 6 Yenisahra 34746 İstanbul
Tel: +90 216 472 83 13 Faks: +90 216 472 83 14 e-posta: info@teknotel.com.tr web: www.teknotel.com.tr

Contents

Running the Program 3

Main Menu 3

Dashboard 4

Online Map 4

Where is my car 6

Reports 7

Statistics 8

Security 9

Running the Program

Figure 1:Desktop Shortcut

For running the program, user should double click the shortcut that created in desktop of computer after installation, after that user will see the main menu of the program.

Main Menu

Figure 2: Main Menu

Main menu includes six submenus such as Dashboard, Online Map, where is my car, Reports, Statistics and Security Recordings, user can select any of them and see the related information or use the operation functions.

Dashboard

Intensity and availability of all parking lots display in dashboard. Important information of whole park and each floor shows in dashboard as figure 3.

Figure 3: Dashboard

Online Map



Figure 4: Online Map

User can view all related parking areas of controllers, displays and direction arrows in online map. Recognized plates also can be seen in related parking slots.

Figure 5: Online Map



Figure 6: Closer Look

User can double click on any parking area and see the picture and other details about parking area.

Figure 7: Camera Reach

Where is my car



Figure 8: Where is my car

It is an easy system to help drivers to find their cars within the shortest time. By inputting license plate number, car owners can check the car location easily and it will show the entry time and axle info. Meanwhile image of car can also be monitored.

User can click security recording button and watch the related video.



Figure 9: Security Recordings

Reports



Figure 10: Reports

The occupancy of park daily, monthly and yearly can be reported. Created graph can be save export and save as an image and also excel file.

- ✓ First report timer should be select daily, monthly or yearly

- ✓ Starting date should be select
- ✓ Report area should be select as whole parking area or desired floor
- ✓ In case of selecting floor, then floor name or number should be select
- ✓ After selecting all the steps create report should be clicked
- ✓ Finally created report can be export as excel file or can be save as an image

Statistics



Figure 11: Statistics

Plate number, controller IP, Entry time interval, exit time interval, floor, stay duration, present vehicles and exited vehicles are searching parameters for creating statistics report. After selecting searching parameters user should click create report button. Finally, user can save the report as pdf, word and excel formats.



Figure 12: Security Recordings

Security recording videos can be searched using controller IP and camera number, also floor and axle can be use as searching parameters.