Parkmaestro
Beyond Parking Guidance

Where is my car?

00 AB 1234

6 Server

1 Entrance VMS Display
Available space counts of Parking Lot.

2 Arrow Display
Available space directions and counts.

3 Floor VMS Display
Availabel space counts of floor.

4 Smart Sensor
Dual camera smart sensor for cars and plates integraled with full color indicator.

www.parkmaestro.com